OWNERS MANUAL

Congratulations on purchasing your VIBE Bluetooth headphones. Please read this manual in order to fully understand how to get the best results from this product and ensure that all advice on how to look after the product is followed.

CONTENTS

The below accessories are subject to change without prior notice..



1. Bluetooth in ear headphones
2. USB charging lead
3. Owners manual
4. Earbuds
5. Travel pouch

SPECIFICATION

Bluetooth specification: Support V2.1 + EDR with handsfree profile 1.5., headset profile 1.1 and AD2P profile 1.2 (Class 2)
Standby time: Up to 100 hours.
Talk time: Up to 10 hours.
Music playback time: Up to 8 hours
Operating distance: Up 10 metres in clear air with no obstructions.
Weight: 16g.
Certification: CE, FCC, RoHS, BQB.

TURNING HEADPHONES ON AND OFF

1. To turn Headphones on, press and hold the multifunction button for around 3 seconds. The blue indicator light will illuminate showing that the headphones are now active.
2. To turn Headphones off, press and hold the multifunction button until the red indicator light illuminates showing that the headphones are now switched off.

PAIRING THE HEADPHONES

1. Ensure that the headphones are switched off.
2. Hold down the multifunction button for about 5 seconds until the red and blue indicator lights start to flash.
3. Activate Bluetooth on your device and search for available devices.
4. Select **VIBEBT1** from the available devices.
5. If prompted for a passkey enter 0000 to finish pairing with the headphones.
6. The blue indicator light will now flash every 2 seconds to indicate that the headphones are now sucessfully paired.

CONTROLS AND FUNCTIONS



1. Multifunction button operates power on / off, answer, end, pair, play, and pause functions.
2. Volume up button.
3. Volume down button.
4. Microphone.
5. Loudspeaker.
6. Previous track button.
7. Next track button.
8. Charging socket.
9. Blue indicator light.
10. Red indicator light..

CHARGING THE HEADPHONES



1. The VIBE Bluetooth in ear headphones feature a built in rechargeable lithium battery.
2. To recharge, connect the supplied USB charging lead to your computer or USB mains plug (not included) and the headphone charging socket.
3. The red indicator light will illuminate to indicate that the headphones are charging.
4. Charging will take around 2 hours, however when charging the headphones for the first time it is recommended that the headphones are charged for at least 4 hours.
5. When the battery is fully charged the red indicator light will turn off.

PHONE OPERATIONS

Answering a call:
Press the multifunction button to answer an incoming call.
Ending a call:
Press the multifunction button while a call is active to end an incoming call.
Making a call:
Select a contact on your phone as usual and select call. The call will now be transferred to the headphones automatically. If your phone does not support this feature press the multifunction button once the call becomes active.
Voice call activation:
*Available only if your phone supports this feature.
When no call is in progress, Press and hold the multifunction button for about 2 seconds and follow the on screen prompts on your phone.
Note: You must have voice dialing enabled on your phone.
Last number redial:
*Available only if your phone supports this feature.
When no call is in progress, Press and press the multifunction button twice.
Rejecting a call:
*Available only if your phone supports this feature.
Press the multifunction button twice to reject an incoming call.
Volume control:
Press either volume key when a call is active to set the call volume.

MUSIC PLAYBACK

To Listen to Music:
Pair and connect your phone or music player to the headphones (see "Pairing the headphones" for more details).
To play music use the playback controls on the connected device.
If used with a phone and you answer a call while music is playing, the music will pause until the call is ended.

Please see the table below for operating functions for music playback:

Function	Operation
Play or Pause	Press the multifunction button (1 ↷)
Increase volume	Press the volume up button (2 +)
Decrease volume	Press the volume down button (3 –)
Previous track	Press previous button (6 ⏮)
Next track	Press next button (7 ⏭)

FITMENT

Please wear the headphones as detailed below.



TROUBLESHOOTING

Interference or poor sound quality:
Ensure that you are not more than 10 metres away from your device and that there are no obstructions such as walls between the headphones and device.
No sound:
- Press the volume up button to increase the volume.
- Ensure that your device is paired with the headphones.
- Ensure that the volume is not set very low on the connected device.

Unable to connect :
- Check the pairing settings on your device, ensure that VIBEBT1 is connected to media audio and phone audio if applicable.
- It may in certain cases be necessary to unpair VIBEBT1 and follow the pairing procedure again.

Additional devices:
The VIBEBT1 Bluetooth headphones are primarily designed for use with Bluetooth enabled phones and media players. It is possible however to also connect other Bluetooth devices with version 1.1, 1.2 and 2.0 compatibility.
Some phone functions do not work:
Pleae check your phone user manual to ensure that the phone has compatibility for the feature and that the phone is correctly set up to use the feature.

MAINTAINANCE

- Always turn the headphones off when not in use.
- Avoid extremely high temperatures (45°C/113°F) and extremely low temperatures (-10°C/14°F). it is also recommended that the product is not stored in direct sunlight.
- Ensure that the volume is not set very low on the connected device.
- High temperatures may damage the battery and the performance of the product.
- Avoid contact with water and other liquids as this may cause irreparable damage to the product.

CAUTION

The VIBE Bluetooth headphones are able to deliver high volume and extreme high frequency sound. Exposure to prolonged high volume and/or excessive high frequency sound may cause permanent damage to your hearing. The volume level may differ from device to device so caution is recommended when using the headphones for the first time and never listen to the headphones at a volume that is uncomfortably loud.

SAFETY GUIDE

Please follow the below advice before using the product.
- Reduce the volume level on the headphones to the minimum setting before using the product and then adjust the volume when the product is in your ears.
- Keep the volume as low as possible during normal use.
- Do not use the product in noisy enviroments as this may have to increase the volume to potentially harmful levels in order to hear the music or your phone.
- If you feel discomfort or pain in your ears, immediately cease using the earphones and seek medical advice.
- Continuous exposure to high volume levels may cause permanent hearing damage without any pain or discomfort.
- It may be dangerous and illegal in some countries to use the headphones when you are driving a car, riding a bike or operating machinery. Please adhere to all local laws and regulations when using this product.
- Keep out of the reach of small children.
- The packaging and products contained within including the plastic bags are not toys. The bag and small parts may cause suffocation.
- Do not attempt to disassemble the product as no parts can be replaced or serviced by the user. Failure to adhere to this warning will invalidate the warranty.
- Product servicing should only be carried out by an authorised VIBE dealer.
- Do not use the product near flammable liquids or gas as this may cause a fire.

WARRANTY

For all warranty information relating to this product please visit the below website:

www.vibeaudio.co.uk/warranty